

### Backrest installation

1. Carefully remove tube closures that are located on top of each side frame of the stool. This should be done by gently inserting a thin screwdriver underneath the tube closure and carefully prying upwards. See ill. A.
2. Remove backrest from carton and place rubber O-rings over inner backrest tubes. See ill. B.
3. Begin installation by aligning metal tubes that protrude from the backrest with the opening of the stool frames. See ill. C.
4. Simultaneously insert both ends of the backrest tubes into the stool opening. Gently push until backrest tubes are flush with stool.
5. Insert the screws into the holes that are located just below the seat on each side of the stool (See ill. D) and tighten them using the provided Alan key.

### Backrest removal

1. Remove screws from frame with provided Alan key.
2. The backrests are built to fit very tightly into the stool frame and some resistance may be encountered while attempting to remove. For easiest removal do not pull from plastic part of backrest but rather place hands at the bottom of the tubes on each side and pull while wiggling the tubes upwards.

