

Combo Table Stool & Spacer Installation Explosion:

Refer to #10-019 for more stool install data

For tables:

MET1012S/C - 10' Elliptical with seating

MTR60S/C - 60" Round with seating

MTO60S/C - 60" Octagon with seating

CRITICAL NOTE:

There are (2) holes in the leg upright.
Top hole is for bench brackets only.

Bottom hole is for stools only.

Steps:

- 1) Slide spacer into stool stem.
- 2) Slide stool onto leg upright with spacer inside stool stem.
- 3) Line up holes in stool with the leg upright holes.
- 4) Install fender washers on each side of stool stem with curve that matches the stool.
- 5) Install bolt and nut. Tighten until the stool does not rotate when grabbed with both hands.

