

ADJUSTABLE HEIGHT LEG ASSEMBLY



6418



6224H



6224HB



6324HB



6418HB

Parts: 4 x Chrome plated adjustable height legs.
4 x Screws for adjustable legs

Tools needed: Philips Head Screwdriver

- Turn stool upside down on a flat sturdy surface.
- Gently pry the plastic glides off the bottom of each leg.
- Insert an "adjustable height leg" into a fixed leg.
- Line up a hole on the "adjustable height leg" with the hole on the fixed leg at the desired height.

- Drive the supplied screw thru both holes & tighten securely.
- Repeat on remaining legs (be sure to align all legs at the same height).

Adjustments to the height can be done by turning the stool upside down, removing the screws & following the above instructions from point 4.

BACKREST INSTALLATION

Parts: 1 x Mounting plate
4 x Screws for mounting plate
1 x Plastic knob
1 x Backrest Arm
1 x Backrest
1 x Bolt & Washer for backrest

Tools needed: Philips Head Screwdriver
Pliers
13-32 Ratchet Driver

- Turn stool upside down onto an elevated flat sturdy surface.
- Identify the four center holes closest to the X (where the legs cross).
- Place the "mounting plate" - flat side down - on the point where the bars cross.
- Align the four holes on the "mounting plate" with the four holes mentioned above.
- Drive supplied screws thru "mounting plate" into crossbars.
- Tighten securely.
- Use the supplied "Alan wrench" to loosen the black screw located on top of mounting plate.
- Insert the shorter -blank end-of the backrest "arm" into the opening of the "mounting plate" with the indentation of the arm aligned with the black screw. Use the "Alan wrench" to tighten the black screw.

- Screw the supplied "knob" into the threaded hole in the center of the "mounting plate" and tighten securely at the desired horizontal location.
- Turn the stool back to its upright position.
- Slide the "backrest" on to the backrest "arm", so that the slot on the "backrest" aligns with the threaded hole in the top edge of the backrest "arm".
- Drive the supplied "bolt & washer" thru the slot of the "backrest" & into the threaded hole on the backrest "arm".
- Tighten securely at the desired height.

Adjustments can be easily made by loosening the backrest bolt or mounting plate knob then adjusting & tightening the bolt or knob at the new desired position.

Note: Some screws & bolts may be slightly difficult to drive initially. In this case some extra force is necessary. Since the screws are self-threading, this will rethread the tubing where necessary.

Dear Customer,

Thank you for your purchase. Although extreme care goes into manufacturing & packaging of this product, mistakes are possible. If you encounter any missing parts or difficulty in assembly, etc. please call our customer service **TOLL FREE** at **1-800-261-4112** for courteous & immediate resolution to your problem.

CAUTION! Double check all screws to be tightened securely before use. Check all screws periodically. Failure to completely tighten the screws may result in tipping & possible injury!