



Part #	(A)	(B)	(C)	(D)	(E)	(F)	(G)	(H)	(I)	(J)	(K)	(L)
Sketch												
Description	Glides	Casters	Base	Column	Column Cover	Footring + height adjusting knob	Seat Bolts	Backrest Bolts	Seat mounting plate with backrest arm	Seat	Backrest	Backrest bracket
Quantity	5	5	1	1	1	1	4	2	1	1	1	1

Base/Column assembly

1. Insert Glides (A) or Casters (B) into each of the five legs of base (C).
2. Insert column (D) firmly into center of base.
3. Slide footring (F) onto column with ring facing upwards and place at desired location.
4. Slide column cover (E) over column.
5. Tighten footring knob well to assure that it stays in place.

Seat assembly

1. Attach seat mounting plate/backrest arm (I) to underside of seat (J) using the provided Allen key to tightly secure the four seat bolts (G).
2. Once seat mounting plate has been attached to seat, place seat over upper portion of column and push down firmly.

Backrest assembly

1. Place inside of backrest bracket (L) over the top rod of the backrest and push it on firmly.
2. Hold backrest (K) over bracket and align holes on bracket to holes on backrest.
3. Using the provided Allen key, tightly secure the two backrest bolts (H) to backrest.

